



Manufacturer	Model Name	Type	Interface	Result	Remark
Avision	<i>MF 3200</i>	MFP	U	Supporting	
Avision	<i>MF 3230</i>	MFP	U	Supporting	
Brother	<i>HL1260</i>	Laser Printer	P	Supporting	
Brother	<i>MFC4800</i>	MFP	U+P	Supporting	
Brother	<i>MFC4800J</i>	MFP	U+P	Supporting	
Brother	<i>MFC6800</i>	MFP	U+P	Supporting	
Brother	<i>MFC7220</i>	MFP	U+P	Supporting	
Brother	<i>MFC7420</i>	MFP	U+P	Supporting	
Brother	<i>MFC8840D</i>	MFP	U+P	Supporting	
Brother	<i>MFC210C</i>	MFP	U	Supporting	
Brother	<i>IntelliFax 2820</i>	MFP	U	Supporting	
Brother	<i>MFC8840</i>	MFP	U	Supporting	
Brother	<i>MFC-7820N</i>	MFP	U	Supporting	
Canon	<i>BJ F9000</i>	InkJet Printer	U	Supporting	
	<i>BJ-330</i>	InkJet Printer	P	Supporting	
CANON	<i>BJC-4200</i>	InkJet Printer	P	Supporting	
CANON	<i>BJC-4300</i>	InkJet Printer	P	Supporting	
CANON	<i>BJC-4550</i>	InkJet Printer	P	Supporting	
CANON	<i>i2355</i>	InkJet Printer	U	Supporting	
CANON	<i>i255</i>	InkJet Printer	U	Supporting	
CANON	<i>i320</i>	InkJet Printer	U	Supporting	
CANON	<i>i355</i>	InkJet Printer	U	Supporting	
CANON	<i>i450</i>	InkJet Printer	U	Supporting	
CANON	<i>i455</i>	InkJet Printer	U	Supporting	
CANON	<i>i470D</i>	InkJet Printer	U	Supporting	
CANON	<i>i475D</i>	InkJet Printer	U	Supporting	
CANON	<i>i550</i>	InkJet Printer	U	Supporting	
CANON	<i>i560</i>	InkJet Printer	U	Supporting	
CANON	<i>i6100</i>	InkJet Printer	U+P	Supporting	
CANON	<i>i6500</i>	InkJet Printer	U+P	Supporting	
CANON	<i>i850</i>	InkJet Printer	U	Supporting	
CANON	<i>i865</i>	InkJet Printer	U	Supporting	
CANON	<i>i9100</i>	InkJet Printer	U	Supporting	
CANON	<i>i950</i>	InkJet Printer	U	Supporting	
CANON	<i>i9950</i>	InkJet Printer	U2.0	Supporting	
CANON	<i>S200SPx</i>	InkJet Printer	U	Supporting	
CANON	<i>S200SRx</i>	InkJet Printer	U	Supporting	
CANON	<i>S520</i>	InkJet Printer	P	Supporting	
CANON	<i>PIXMA ip1000</i>	InkJet Printer	U	Supporting	

Manufacturer	Model Name	Type	Interface	Result	Remark
CANON	<i>PIXMA ip2000</i>	InkJet Printer	U	Supporting	
CANON	<i>PIXMA ip3000</i>	InkJet Printer	U	Supporting	
CANON	<i>PIXMA ip4000</i>	InkJet Printer	U+P	Supporting	
CANON	<i>PIXMA ip5000</i>	InkJet Printer	U	Supporting	
CANON	<i>PIXMA ip6000D</i>	InkJet Printer	U	Supporting	
CANON	<i>PIXMA ip8500</i>	InkJet Printer	U	Supporting	
CANON	<i>MP-110</i>	MFP	U	Supporting	
CANON	<i>MP-130</i>	MFP	U	Supporting	
CANON	<i>MP170</i>	MFP	U	Supporting	
CANON	<i>MP150</i>	MFP	U	Supporting	
CANON	<i>MP450</i>	MFP	U	Supporting	
CANON	<i>MP730</i>	MFP	U	Supporting	
EPSON	<i>Aculaser C1900</i>	Color Laser Jet	U+P	Supporting	
	<i>EPL-5700</i>	Laser Printer	P	Supporting	
EPSON	<i>EPL-6100</i>	Laser Printer	U+P	Supporting	Disable bidirectional Support
EPSON	<i>LQ-100</i>	DotMaxtrix Printer	P	Supporting	
EPSON	<i>LQ-1000C</i>	DotMaxtrix Printer	P	Supporting	
EPSON	<i>LQ-1170C</i>	DotMaxtrix Printer	P	Supporting	
EPSON	<i>LQ-2080C</i>	DotMaxtrix Printer	P	Supporting	
EPSON	<i>LQ-2170C</i>	DotMaxtrix Printer	P	Supporting	
EPSON	<i>LQ-300+</i>	DotMaxtrix Printer	P	Supporting	
EPSON	<i>LQ-570C</i>	DotMaxtrix Printer	P	Supporting	
EPSON	<i>LQ-570C+</i>	DotMaxtrix Printer	P	Supporting	
EPSON	<i>Stylus C20</i>	InkJet Printer	USB	Supporting	Disable bidirectional Support
EPSON	<i>Stylus C20SX</i>	InkJet Printer	USB	Supporting	Disable bidirectional Support
EPSON	<i>Stylus C40</i>	InkJet Printer		Supporting	Disable bidirectional Support
EPSON	<i>Stylus C43UX</i>	InkJet Printer	USB	Supporting	
EPSON	<i>Stylus C60</i>	InkJet Printer		Supporting	Disable bidirectional Support
EPSON	<i>Stylus C63</i>	InkJet Printer	U+P	Supporting	
EPSON	<i>Stylus C83</i>	InkJet Printer	U+P	Supporting	
EPSON	<i>Stylus C670</i>	InkJet Printer	U	Supporting	
EPSON	<i>Stylus Color 1160</i>	InkJet Printer		Supporting	Disable bidirectional Support
EPSON	<i>Stylus Color 1520</i>	InkJet Printer		Supporting	Close printer utility
EPSON	<i>Stylus Color 1520K</i>	InkJet Printer		Supporting	Close printer utility
EPSON	<i>Stylus Color 400</i>	InkJet Printer	P	Supporting	Close printer utility
EPSON	<i>Stylus Color 600</i>	InkJet Printer	P	Supporting	Close printer utility
EPSON	<i>Stylus Color 670</i>	InkJet Printer	U+P	Supporting	
EPSON	<i>Stylus Color 800</i>	InkJet Printer		Supporting	Close printer utility

Manufacturer	Model Name	Type	Interface	Result	Remark
EPSON	<i>Stylus Color 810</i>	InkJet Printer		Supporting	
EPSON	<i>Stylus Photo 915</i>	InkJet Printer	U	Supporting	
EPSON	<i>Stylus Photo1270</i>	InkJet Printer	U+P	Supporting	
EPSON	<i>Stylus Photo2100</i>	InkJet Printer		Supporting	
EPSON	<i>Stylus Photo810</i>	InkJet Printer		Supporting	
EPSON	<i>Stylus PhotoEX3</i>	InkJet Printer	U+P	Supporting	There is error message when is printing.
EPSON	<i>EPL-5800</i>	Laser Printer	U+P	Supporting	
EPSON	<i>EPL-5900</i>	Laser Printer		Supporting	
EPSON	<i>EPL-6200</i>	Laser Printer	U+P	Supporting	
EPSON	<i>LP 2500</i>	Laser Printer	U	Non-Supporting	
EPSON	<i>LP 8900</i>	Laser Printer	U	Supporting	
EPSON	<i>Stylus Photo830U</i>	InkJet Printer	U	Supporting	
EPSON	<i>TM-T88III</i>	Thermal Printer	U+P	Supporting	
EPSON	<i>Stylus CS-1500</i>	MFP	U	Supporting	
EPSON	<i>Stylus CX-3500</i>	MFP	U	Supporting	
EPSON	<i>Stylus CX-4700</i>	MFP	U	Supporting	
EPSON	<i>Stylus CX-5300</i>	MFP	U	Supporting	
EPSON	<i>Stylus CX-3700</i>	MFP	U	Supporting	
EPSON	<i>Stylus CX-4100</i>	MFP	U	Supporting	
EPSON	<i>Stylus Photo RX430</i>	MFP	U	Supporting	
EPSON	<i>Stylus Photo RX510</i>	MFP	U	Supporting	
EPSON	<i>Stylus Photo RX530</i>	MFP	U	Supporting	
EPSON	<i>Stylus Photo RX630</i>	MFP	U	Supporting	
EPSON	<i>Stylus C900</i>	InkJet Printer	U	Supporting	
EPSON	<i>R210</i>	InkJet Printer	U	Supporting	
	<i>DL 3800 中文機</i>	DotMaxtrix Printer	P	Supporting	
	<i>DL 700</i>	DotMaxtrix Printer	P	Supporting	
FUJITSU	<i>DL6800</i>	DotMaxtrix Printer	P	Supporting	
FUJITSU	<i>PP 10</i>	Laser Printer	P	Supporting	
FUJITSU	<i>DL 6400</i>	DotMaxtrix Printer	P	Supporting	
FUJITSU	<i>DL 900</i>	DotMaxtrix Printer	P	Supporting	
	<i>DeskJet 1125C</i>	InkJet Printer	U+P	Supporting	Disable bidirectional Support
	<i>DeskJet 1220C</i>	InkJet Printer	U+P	Supporting	Disable bidirectional Support
HP	<i>DeskJet 3650</i>	InkJet Printer	U	Supporting	
HP	<i>DeskJet 400</i>	InkJet Printer	P	Supporting	
HP	<i>DeskJet 500</i>	InkJet Printer	P	Supporting	

Manufacturer	Model Name	Type	Interface	Result	Remark
HP	<i>DeskJet 5500</i>	Color Laser Jet	P	Supporting	
HP	<i>DeskJet 5550</i>	InkJet Printer	U+P	Supporting	
HP	<i>DeskJet 670C</i>	InkJet Printer	P	Supporting	
HP	<i>DeskJet 680C</i>	InkJet Printer	P	Supporting	
HP	<i>DeskJet 720C</i>	InkJet Printer	P	Supporting	
HP	<i>DeskJet 810C</i>	InkJet Printer	P+U	Supporting	
HP	<i>DeskJet 845C</i>	InkJet Printer	U	Supporting	
HP	<i>DeskJet 920C</i>	InkJet Printer	U+P	Supporting	
HP	<i>Deskjet 1180c</i>	InkJet Printer	U+P	Supporting	
HP	<i>DeskJet 930C</i>	InkJet Printer	U+P	Supporting	
HP	<i>LaserJet 1100</i>	Laser Printer	P	Supporting	
HP	<i>LaserJet 1200</i>	Laser Printer	U+P	Supporting	Disable bidirectional Support
HP	<i>LaserJet 1220</i>	Laser Printer	U+P	Supporting	Disable bidirectional Support
HP	<i>LaserJet 1300</i>	Laser Printer	U+P	Supporting	
HP	<i>LaserJet 2200</i>	Laser Printer	U+P	Supporting	Disable bidirectional Support
HP	<i>LaserJet 2200D</i>	Laser Printer	U+P	Supporting	Disable bidirectional Support
HP	<i>LaserJet 3330</i>	Laser Printer	U+P	Supporting	
HP	<i>LaserJet 4000</i>	Color Laser Jet	P	Supporting	
HP	<i>LaserJet 5000</i>	Color Laser Jet	U+P	Supporting	Support PCL5 or PCL5 Driver
HP	<i>LaserJet 5000LE</i>	Color Laser Jet	U+P	Supporting	Support PCL5 or PCL6 Driver
HP	<i>LaserJet 6P</i>	Laser Printer	P	Supporting	
HP	<i>Photosmart 7150</i>	Photo Printer	USB	Supporting	
HP	<i>Photosmart 2610</i>	MFP	U	Supporting	
HP	<i>LaserJet 1500L</i>	Color Laser Jet	U2.0	Supporting	Only support Host-based.
HP	<i>PSC 1315</i>	Color MFP	USB	Supporting	
HP	<i>DeskJet 3535</i>	InkJet Printer	U	Supporting	
HP	<i>DeskJet 5550</i>	InkJet Printer	U	Supporting	
HP	<i>DeskJet 5652</i>	InkJet Printer	U+P	Supporting	
HP	<i>LaserJet 2300</i>	Laser Printer	U+P	Supporting	
HP	<i>LaserJet 2420</i>	Laser Printer	U 2.0	Supporting	
HP	<i>LaserJet 4250</i>	Laser Printer	U2.0+P	Supporting	
HP	<i>LaserJet 2550</i>	Color Laser Jet	U2.0+P	Supporting	
HP	<i>LaserJet 3015</i>	MFP	U+P	Supporting	
HP	<i>PSC 1315</i>	MFP	U	Supporting	
HP	<i>PSC 1350</i>	MFP	U	Supporting	
HP	<i>PSC 1410</i>	MFP	U	Supporting	
HP	<i>PSC 1610</i>	MFP	U	Supporting	
HP	<i>PSC 2310</i>	MFP	U	Supporting	

Manufacturer	Model Name	Type	Interface	Result	Remark
HP	OfficeJet 4255	MFP	U	Supporting	
HP	OfficeJet 5510	MFP	U	Supporting	
HP	OfficeJet 6210	MFP	U	Supporting	
HP	OfficeJet 7210	MFP	U	Supporting	
HP	OfficeJet K80	MFP	U	Non-Supporting	
HP	OfficeJet 6610	MFP	U	Supporting	
HiTi	S400	Photo Printer	U	Supporting	
HiTi	Photo Printer 730PS/GALA	Photo Printer	U	Supporting	
HiTi	Photo Printer 730PL	Photo Printer	U	Supporting	
HiTi	Photo Printer 641PS	Photo Printer	U	Supporting	
HiTi	Photo Printer 640PS	Photo Printer	U	Supporting	
HiTi	Photo Printer 640GALA	Photo Printer	U	Supporting	
HiTi	Photo Printer 640DL	Photo Printer	U	Supporting	
HiTi	Printer 640Amphi	Photo Printer	U	Supporting	
HiTi	Printer 640GOLD	Photo Printer	U	Supporting	
	Infoprint 1332	FALSE	U+P	Supporting	
	Infoprint 1412	FALSE	U+P	Supporting	
IBM	Infoprint 20	FALSE	P	Supporting	
	FS-1010	Laser Printer	U+P	Supporting	
	FS-1020D	Laser Printer	U+P	Supporting	
KYOCERA	FS-1920	Laser Printer	U+P	Supporting	
KYOCERA	FS-720	Laser Printer	U+P	Supporting	
KYOCERA	FS-820	Laser Printer	U+P	Supporting	
KYOCERA	FS-920	Laser Printer	U+P	Supporting	
KYOCERA	FS-6020	Laser Printer	U+P	Supporting	
KYOCERA	1380MF	MFP	U	Supporting	
KYOCERA	FS-1010KX	Laser Printer	U	Supporting	
KONICA	PagePro 1350W	Laser Printer	U+P	Supporting	
KONICA	Magicolor 2300w	Color Laser Jet	U+P	Supporting	
KONICA	PagePro 1380MF	Color Laser Jet	U	Supporting	
	C720	Color Laser Jet	P	Supporting	
	C750	Color Laser Jet	U+P	Supporting	
LEXMARK	E210	Laser Printer	U+P	Supporting	
LEXMARK	E322	Laser Printer	U+P	Supporting	
LEXMARK	Optra S 1250	Laser Printer	P	Supporting	
LEXMARK	T420	Laser Printer	P+U+E	Supporting	
LEXMARK	T620	Laser Printer	P+U+RS-232	Supporting	

Manufacturer	Model Name	Type	Interface	Result	Remark
LEXMARK	<i>W812</i>	Laser Printer	P+U+E	Supporting	
LEXMARK	<i>Z42</i>	InkJet Printer	U	Supporting	
LEXMARK	<i>Z43</i>	InkJet Printer	U+P	Supporting	
LEXMARK	<i>Z45</i>	InkJet Printer	U	Supporting	
LEXMARK	<i>Z55</i>	InkJet Printer	U+P	Supporting	
LEXMARK	<i>Z705</i>	InkJet Printer	U	Supporting	
LEXMARK	<i>E230</i>	Laser Printer	U	Supporting	
LEXMARK	<i>X6170</i>	MFP	U	Supporting	
LEXMARK	<i>Z515</i>	InkJet Printer	U	Supporting	
LEXMARK	<i>X3330</i>	MFP	U	Supporting	
LEXMARK	<i>X2350</i>	MFP	U	Supporting	
LEXMARK	<i>X1195</i>	MFP	U	Non-Supporting	
LEXMARK	<i>X3350</i>	MFP	U	Supporting	
LEXMARK	<i>X4250</i>	MFP	U	Supporting	
LEXMARK	<i>X7170</i>	MFP	U	Supporting	
LEXMARK	<i>X4270</i>	MFP	U	Supporting	But the fax can't work.
LEXMARK	<i>X1185</i>	MFP	U	Non-Supporting	
LEXMARK	<i>X5250</i>	MFP	U	Supporting	
LEXMARK	<i>P3150</i>	MFP	U	Supporting	
LEXMARK	<i>X2250</i>	MFP	U	Supporting	
LEXMARK	<i>X6170</i>	MFP	U	Supporting	
LEXMARK	<i>X5150</i>	MFP	U	Supporting	
NEC	<i>Pinwriter P2200</i>	DotMaxtrix Printer	P	Supporting	
	<i>Pinwriter P3200</i>	DotMaxtrix Printer	P	Supporting	
NEC	<i>Pinwriter P5300</i>	DotMaxtrix Printer	P	Supporting	
NEC	<i>Pinwriter P8000C</i>	DotMaxtrix Printer	P	Supporting	
OKI	<i>ML-391</i>	DotMaxtrix Printer	P	Supporting	
OKI	<i>B4350</i>	Laser Printer	U+P	Supporting	
Panasonic	<i>KX-P1121</i>	DotMaxtrix Printer	P	Supporting	
PANASONIC	<i>KX-P1123</i>	DotMaxtrix Printer	P	Supporting	
PANASONIC	<i>KX-P1124</i>	DotMaxtrix Printer	P	Supporting	
PANASONIC	<i>KX-P1624</i>	DotMaxtrix Printer	P	Supporting	
PANASONIC	<i>KX-P6500</i>	Laser Printer	P	Supporting	
SAMSUNG	<i>ML-1710</i>	Laser Printer	U	Supporting	
SAMSUNG	<i>ML-1750</i>	Laser Printer	U+P	Supporting	
SAMSUNG	<i>SRP-270</i>		P	Supporting	
SAMSUNG	<i>Star NX-2420</i>	DotMaxtrix Printer	P	Supporting	
SAMSUNG	<i>CLP-500</i>	Laser Printer	U+P	Supporting	

Manufacturer	Model Name	Type	Interface	Result	Remark
SAMSUNG	<i>CLP-510</i>	Laser Printer	U	Supporting	
SAMSUNG	<i>ML-1520</i>	Laser Printer	U	Supporting	
SAMSUNG	<i>ML-2250</i>	Laser Printer	U+P	Supporting	
SAMSUNG	<i>ML-2550</i>	Laser Printer	U+P	Supporting	
SAMSUNG	<i>SCX-4016</i>	MFP	U+P	Supporting	
SAMSUNG	<i>SCX-4100</i>	MFP	U+P	Supporting	
SHARP	<i>AR-M160</i>	MFP		Supporting	
SHARP	<i>AR-M185</i>	MFP		Supporting	
SHARP	<i>AR-M205</i>	MFP		Supporting	
SHARP	<i>AR-M235</i>	MFP	U+P	Supporting	
SHARP	<i>AR-M275</i>	MFP	U+P	Supporting	
SHARP	<i>AR-M350</i>	MFP	U+P	Supporting	
SHARP	<i>AR-M450</i>	MFP	U+P	Supporting	
XEROX	<i>Phaser 3310</i>	Laser Printer	U+P	Supporting	
	<i>DocuPrint 240A</i>	Laser Printer	U+P	Supporting	
FujiXerox	<i>Document 203A</i>	MFP	U	Supporting	